



**enertexbayern** gmbh  
simulation entwicklung consulting

Manual and Configuration

# KNXnet/IP Router



**Note**

The contents of this document may be reproduced without prior written approval by Enertex® Bayern GmbH in any form, neither in whole nor in parts, copied, transmitted, distributed or stored.

Enertex® is a registered trademark of Enertex® Bayern GmbH. Other product and company names mentioned in this manual may be the marketing or trade names of their respective owners.

This manual may be changed without notification or announcement and makes no claim to completeness or accuracy.

## Table of content

<b>Notices.....</b>	<b>3</b>
<b>Assembly and connection.....</b>	<b>3</b>
<b>Commissioning.....</b>	<b>3</b>
<b>Functional Description.....</b>	<b>4</b>
<b>ETS-Topology.....</b>	<b>4</b>
<b>Parameterization.....</b>	<b>4</b>
<i>General.....</i>	<i>4</i>
<i>IP settings.....</i>	<i>4</i>
<i>Routing (KNX → IP).....</i>	<i>5</i>
<i>Routing (IP → KNX) .....</i>	<i>6</i>
<b>Telnetserver.....</b>	<b>6</b>
<b>Reset to factory defaults.....</b>	<b>8</b>
<b>ETS product data.....</b>	<b>8</b>
<b>Technical data.....</b>	<b>8</b>
<b>Obligation for distributors under § 18 (1) Battery Act .....</b>	<b>9</b>

## Notices


- Installation and assembly of electrical equipment must be performed by qualified electricians.
- When connecting KNX/EIB interfaces skills are provided by KNX™-Training.
- Ignoring the instructions may damage the device as well as causing fire or other hazards.
- This manual is part of the product and must remain with the end user.
- The manufacturer is not liable for any costs or damages incurred by the user or third parties through the use of this device, misuse or malfunction of the connection, malfunction of the device or the subscriber equipment.
- Opening the case or other authorized changes or modifications will void the warranty!
- The manufacturer is not liable for improper use.

## Assembly and connection

Requirements:

- One of the following power supplies
  - 20 bis 30 V DC
  - 16 bis 24 V AC
  - „Power over Ethernet“ (IEEE 802.3af), Class 1
  - AUX-Output of the Enertex® KNX PowerSupply 960 if there is no additional KNX choke connected to it
- 10/100 Mbit compatible Ethernet connection
- KNX/EIB bus connection

## Commissioning



LCD shows product name and firmware version at startup. Boottime is about 2 seconds.

The default network setting is DHCP.

If the DHCP server has transmitted a valid IP address to the device, it is shown in the first line of the LCD with the prefix „D“.

If you set a static IP „S“ occurs or rather „Z“ for a IP address procured via Zeroconf.

In the second row the KNX physical address is displayed (prefix „K“). To use the routing functions it has to look like „x.y.0“ or „x.0.0“ (x,y: value between 0 and 15).

„T“, followed by a number between 0 and 5 shows the number of the open tunnel connection.

The green LED signalizes LAN activity, the yellow LED signalizes KNX bus activity. If the red LED is active, device is in programming mode.

## Functional Description

- Five independent KNXnet/IP tunnel connections
- KNXnet/IP Routing for communication between KNX lines, areas und systems via IP network
- Telegram routing and filtering according to physical address or group address
- LED-signaling for KNX communication, Ethernet communication and programming mode
- Standard configuration with ETS
- Configuration of the tunnel addresses via Telnet
- SNTP Server with battery-buffered real-time clock

## ETS-Topology

To add the device in a ETS project, the project needs a IP-Backbone, as shown in the following example:




### Lines:

- **0.0:** Medium IP
- **1.0:** Medium IP
- **1.1:** Medium TP

## Parameterization

The device can be parameterized with ETS3, ETS4 or ETS5. It supports up to five tunnel connections and can be used as a line- or area coupler.

### General



**Device name** You can assign a user-defined name here (up to 30 characters).

**Bus power failure monitoring** Reports a KNX bus failure to the IP network, als well as the re-storation.

*Parameter:* enabled, disabled

### IP settings

**IP assignment method** The IP address can be assigned via DHCP, Manually or Zeroconf.

*Parameter:* manuell, DHCP, Zeroconf

IP-Adressvergabe	DHCP	
Routing-Multicast-Adresse:		
x._._ - [224...239]	224	
._x._ - [0...255]	0	
._.x._ - [0...255]	23	
._._x - [0...255]	12	

**Routing Multicast Address** This address will be used for routing telegrams on IP side. The Multicast IP Address 224.0.23.12 has been reserved for this purpose (KNXnet/IP Routing). If you want to assign another address it has to be in the range between 224.0.0.0 and 239.255.255.255.

**IP Address** (only for manual assignment)

IP-Adresse:	
x._._	192
._x._	168
._.x._	1
._._x	181

*Parameter: valid IP address in your network*

**Subnet Mask** (only for manual assignment)

Subnetzmaske:	
x._._	255
._x._	255
._.x._	255
._._x	0

*Parameter: valid subnet mask*

**Default Gateway** (only for manual assignment)

Subnetzmaske:		
x._._	255	
._x._	255	
._.x._	255	
._._x	0	

*Parameter: valid IP address in your network*

## Routing (KNX → IP)

Gruppentelegramme der Hauptgruppen 0 bis 13	filtern (Standard)
Gruppentelegramme der Hauptgruppen 14 bis 15	weiterleiten (Standard)
Physikalisch adressierte Telegramme	filtern (Standard)
Broadcast-Telegramme	weiterleiten (Standard)

**Group telegrams of main group 0 to 13** Via routing group telegrams can be forwarded,

blocked or filtered. You can parameterize the behaviour of the main groups 0 to 13 different to the behaviour of the main groups 14 to 15. If you choose „filter“, ETS will select the relevant telegrams to route automatically.

*Parameter:* filter, block, route

### Group telegrams of main group 14 to 15

*Parameter:* block, route

**Physically addressed telegrams** Physically addressed telegrams (e.g. programming of actuators) can be routed, blocked or filtered.

*Parameter:* filter, block, route

### Broadcast telegrams

*Parameter:* block, route

## Routing (IP → KNX)

Gruppentelegramme der Hauptgruppen 0 bis 13	filtern (Standard)
Gruppentelegramme der Hauptgruppen 14 bis 15	weiterleiten (Standard)
Physikalisch adressierte Telegramme	filtern (Standard)
Broadcast-Telegramme	weiterleiten (Standard)

**Group telegrams of main group 0 to 13** Via routing group telegrams can be forwarded, blocked or filtered. You can parameterize the behaviour of the main groups 0 to 13 different to the behaviour of the main groups 14 to 15. If you choose „filter“, ETS will select the relevant telegrams to route automatically.

*Parameter:* filter, block, route

### Group telegrams of main group 14 to 15

*Parameter:* block, route

**Physically addressed telegrams** Physically addressed telegrams (e.g. programming of actuators) can be routed, blocked or filtered.

*Parameter:* filter, block, route

### Broadcast telegrams

*Parameter:* block, route

## Telnetserver

A integrated Telnet server provides additional functionalities. The default password for Telnet access is „knxnetip“.

<b>date</b>	Show time (UTC) and date # date 15:50:19 21.04.2017 (UTC)
<b>factory_reset</b>	Reset the device to factory default and restart
<b>ifconfig</b>	Show IP settings # ifconfig IP.....: 192.168.22.253 Subnet mask...: 255.255.255.0 Gateway.....: 192.168.22.69 NTP server....: 192.53.103.108 Sys multicast.: 224.0.23.12 RT multicast...: 224.0.23.12 Hardware addr.: 00:50:c2:79:30:03  Sys multicast: multicast address for system telegrams RT multicast: multicast address for routing telegrams

<b>lcconfig</b>	<p>Show KNXnet/IP routing setting</p> <pre># lcconfig Coupler type.: line coupler IP -&gt; KNX: GA 0-13.....: filter GA 14-15.....: route Ph. add.....: route Broadcast.....: route KNX -&gt; IP: GA 0-13.....: filter GA 14-15.....: route Ph. add.....: route Broadcast.....: route PW fail. mon.: enabled</pre> <p>IP-&gt;KNX: settings for telegrams from IP to KNX  KNX-&gt;IP: settings for telegrams from KNX to IP  GA 0-13: group telegrams of main groups 0 to 13  GA 14-15: group telegrams of main groups 14 to 15  Ph. addr.: physical addressed telegrams  Broadcast: broadcast telegrams  PW fail. mon.: power fail monitor</p>
<b>logout</b>	Close Telnet session
<b>passwd oldpw newpw</b> <b>passwd oldpw</b> <b>passwd newpw</b>	<p>Change Telnet password (<i>passwd old new</i>),  Delete password (<i>passwd old</i>)  Set password, if no password is set already (<i>passwd new</i>)</p>
<b>lock [0 1]</b>	<p>Show „Lock“ status (without option) or change lock mode (0 = off, 1 = on)</p> <p>With filtering a router can prevent forwarding of physically addressed telegrams, which makes it impossible to re-program devices at another line. That's important for outside areas/lines.</p> <p>Though it's possible to re-program the router itself to enable routing of physical addressed telegrams by accessing the bus at an outdoor line with e.g. a USB-KNX-Interface. This can be prohibited by this Telnet function. Set „lock“ to 1 to disable reprogramming of the router.</p>
<b>progmode [0 1]</b>	<p>Show programming mode status (without option) or set programming mode (0 = off, 1 = on)</p> <pre># progmode Programming mode: off  # progmode 1 Programming mode: on  # progmode 0 Programming mode: off</pre>
<b>reboot</b>	Restart device
<b>sntp [query server IP]</b>	<p>Send ntp query (<i>sntp query</i>) or set IP address of the NTP server (<i>sntp server 1.2.3.4</i>)</p> <pre># sntp query Sending SNTP query to 192.53.103.108  # sntp server 1.2.3.4 NTP server...: 1.2.3.4</pre>
<b>stats</b>	<p>Show statistics</p> <pre># stats uptime: 1 days, 20:29 KNX communication statistics: TX to IP (all): 384690 (ca. 144 t/m) TX to KNX: 8826 (ca. 3 t/m) RX from KNX: 110487 (ca. 41 t/m) Overflow to IP: 1 Overflow to KNX: 0 TX tunnel re-req: 47</pre> <p>uptime: uptime since last reboot  TX to IP (all): number of telegrams sent to IP  TX to KNX: number of telegrams sent to KNX bus  RX from KNX: number of telegrams received from KNX bus  Overflow to IP: number of telegrams, that couldn't be sent to IP  Overflow to KNX: number of telegrams, that couldn't be sent to KNX bus  TX tunnel re-req: number of telegrams, that had to be repeated during tunnel access</p>
<b>tpconfig</b>	<p>Show KNX parameters</p> <pre># tpconfig KNX bus state.: up KNX address...: 00.01.000 Serial number.: 00-a5-00-00-00-03</pre> <p>KNX bus state: KNX bus detected (up) or not detected (down)  KNX address: physical address of the device  Serial number: serial number of the device</p>

<b>tunaddr 1..5 address</b> <b>tunaddr reset</b>	Change tunnel address for each tunnel e.g. <i>tunaddr 1 15.15.240</i> or reset tunnel addresses to factory default ( <i>tunaddr reset</i> ) # tunaddr setall 0.1.240 Setting all tunnel KNX addresses.. 1: New KNX address: 00.01.240 2: New KNX address: 00.01.241 3: New KNX address: 00.01.242 4: New KNX address: 00.01.243 5: New KNX address: 00.01.244 done  # tunaddr 1: KNX address: 00.01.240 2: KNX address: 00.01.241 3: KNX address: 00.01.242 4: KNX address: 00.01.243 5: KNX address: 00.01.244
<b>tunnel [1..5]</b>	Show tunnel addresses and connection status (without option), or show detailed information for a specific tunnel (option 1..5) # tunnel Tunnels open: 2/5 1: 00.01.240, closed 2: 00.01.241, open (CCID: 2) 3: 00.01.242, open (CCID: 211) 4: 00.01.243, closed 5: 00.01.244, closed  # tunnel 2 Tunnel 2.....: open (CCID 2) KNX address...: 00.01.241 HPAI control...: 192.168.22.249:4808 HPAI data.....: 192.168.22.249:4808 Connect. type.: TUNNEL_CONNECTION TX tun req....: 118537 TX tun re-req.: 0 RX tun req....: 2550 RX tun re-req (identified): 0 RX tun req (wrong seq.)...: 0  CCID: connection id of the tunnel connection KNX address: tunnel address HPAI control: control-end-point of the receiver HPAI data: data-end-point of the receiver Connect. Type: tunnel connection or management connection TX tun req: number of telegrams sent to this tunnel TX tun re-req: number of telegrams that had to be repeated for this tunnel connection RX tun req: number of telegrams received from this tunnel RX tun re-req: number of telegrams that have been received twice for this tunnel connection RX tun req (wrong seq.): number of telegrams with wrong sequence number that have been received for this tunnel
<b>version</b>	Show firmware version # version Firmware version: 1.042

## Reset to factory defaults

To reset the device to factory defaults, press and hold the programming mode button for three seconds. When the red LED starts blinking release the button. The device shuts down and will reboot with factory settings automatically.

## ETS product data

You can download the latest version of the product's ETS database from our homepage:

<http://www.enertex.de/e-downloads01.php>

## Technical data

Power supply	16-24 V AC or 20-30 V DC; IEEE 802.3af („Power over Ethernet“)
Power consumption	Max. 1 W
Display	2-line LCD
KNX functions	KNXnet/IP tunneling and routing



KNXnet/IP routing	Up to 48 telegrams per second
KNXnet/IP tunneling	Up to 35 telegrams per second, up to five tunnel connections
NTP	SNTP Server, battery-buffered


## Obligation for distributors under § 18 (1) Battery Act

Dear customer, you bought a battery operated product from us. Although the battery life is very long, it still needs to be disposed someday. Used batteries should not be put in the household garbage. Consumers are required by law to bring batteries to a suitable collection point. You can also send your used batteries to

Enertex Bayern GmbH  
Ebermannstädter Str. 8  
91301 Forchheim  
Deutschland

Old batteries contain valuable raw materials that can be recycled.

The environment and Enertex Bayern GmbH say thank you.



The garbage bin symbol means: Batteries and rechargeable batteries must not be disposed of with household waste.