



enertex bayern gmbh
simulation entwicklung consulting

Manual and Configuration

Enertex® KNX IP Secure Interface



Note

The content of this document may not be reproduced, distributed, distributed or stored in any form whatsoever, in whole or in part, without the prior written consent of Enertex® Bayern GmbH.

Enertex® is a registered trademark of Enertex® Bayern GmbH. Other product and company names mentioned in this manual may be trademarks or trade names of their respective owners.

This manual is subject to change without notice or announcement and does not claim to be complete or correct.

Inhalt

Sicherheitshinweise	3
Montage und Anschluss	3
Inbetriebnahme	3
<i>Boot</i>	3
<i>Anzeigen</i>	3
<i>Reset</i>	4
Funktionsübersicht	4
ETS Parameter	4
<i>Begriffe</i>	4
<i>ETS 5.6.6 und ETS 5.7.0</i>	5
Versionsvoraussetzungen.....	5
Besonderheiten.....	5
<i>Topologie</i>	6
<i>Geräte Eigenschaften</i>	7
Allgemein.....	7
IP-Einstellungen.....	7
<i>Gerätespezifische Parameter</i>	8
Allgemein.....	8
Spezialfunktionen.....	8
Verhalten der KNX Seite	8
Standard Tunnel bevorzugte IP.....	9
Routing.....	11
Filter Geräteadresse (physikalisch adressierte Telegramme).....	11
Filter Gruppenadressen.....	12
Standard.....	12
Erweiterter Gruppenadressfilter.....	13
Telnet	15
Aktuelle Daten	18
Technische Daten	18
Open Source Software	19
<i>LWIP</i>	19

Security Notes

- Installation and assembly of electrical equipment may only be carried out by qualified electricians.
- When connecting KNX / EIB interfaces, KNX™ training is required.
- Failure to observe this instruction may result in damage to the unit, fire or other hazards.
- This guide is part of the product and must remain with the end user.
- The manufacturer is not liable for costs or damages caused to the user or third parties by the use of this device, misuse or interference of the connection, malfunctions of the device or of the subscriber devices.
- The opening of the housing, other unauthorized modifications and / or conversions to the device will void the guarantee!
- The manufacturer shall not be liable for any inappropriate use.

Assembly and connection

To operate the Enertex® KNX IP Secure Interface, you need:

- A 10/100 Mbit compatible Ethernet connection
- KNX / EIB bus connection

Commissioning

Boot

When powered the display shows the product name. The default for the network is DHCP. The boot time is about 2 seconds. During this time, the green / red / yellow LEDs operate as running light for a short time. At the end of the boot process, the IP address of the device is shown in the display.

If the IP address assignment is done via DHCP server, the boot time is extended accordingly. As soon as "KNX Ready" appears in the display, the device can be addressed via the bus and, for example, alternatively be programmed via a USB interface. The green LED flashes every second with a duty cycle of 1:30.

Displays

After one minute, the display turns off automatically.

To turn this on again, the DISPLAY button on the front panel must be pressed briefly. When the display is activated, pressing the DISPLAY button will scroll through various pages of information.

Page 1 shows the firmware version, IP address, physical address, serial number, bus voltage and used tunnel connections.

Page 2 shows all IP settings, as well as the boot time.

Page 3 gives information about the telegram load.

Page 4 shows the FDSK as long as the device has not been set to the secure state.

There are three LEDs on the front. The green LED flashes every second with a duty cycle of 1:30 and indicates ready for operation. The red LED indicates the programming mode, the yellow LED indicates bus activity.

In the LAN socket two further LEDs are installed. The green indicates a connection to another IP

device or switch ("Link"), the yellow LED shows the IP data transfer.

Reset

If the device is to be reset to the factory settings, the PROG button on the front panel must be pressed for 10 seconds. After this time, the red LED starts to flash - then the PROG key can be released and the device carries out the reset to the delivery condition.

Functional Overview

The device has the following functions:

- KNX IP Secure
 - Eight independent KNXnet / IP tunnel connections
 - Communication via TCP or UDP for communication
 - KNX IP tunneling in encrypted (secure) mode.
- Displays
 - LED displays for KNX communication, Ethernet communication and programming mode
 - Power indicator
 - OLED display for status messages, parameter displays etc.
- Special functions
 - Configuration via ETS and Telnet
 - SNTP server
 - Measurement of the TP bus voltage, TP bus current and temperature (Telnet, OLED display)
 - Maximum TP APDU packet length of the KNX bus (248 bytes)
 - Maximum TP packet length adjustable (Telnet) between 55 and 248 bytes (APDU)
 - Simulation of UDP tunnels for ETS communication (Telnet)
- Performance
 - Specification of a max. TP data rate for writing KNX telegrams
 - Buffering up to 256 telegrams per tunnel (2048 in total) in the device on the IP side
 - Buffering up to 1024 telegrams for telegrams from IP to TP

ETS Parameter

Terms

Encryption, encrypted If devices send data information via the TP bus or IP network, they are generally readable by third parties. These only require access to the TP bus or IP network for reading. Encryption of the data in this context means that the contents of the telegrams are no longer to be interpreted if the encryption parameters (for example passwords) are unknown.

Key, Key Parameter A series of numbers known only to the ETS project. These numbers are used to transform the data in both directions: encryption and decryption.

FDSK (Factory Default Setup Key) The initial factory key. This key is used when commissioning the initial programming. A new key is loaded into the device, whereby this

process is encrypted with the FDSK. The FDSK key is then no longer valid. It is reactivated only when resetting to factory settings.

Backbone For IP devices, this is always the IP network.

Multicast An IP address in the network over which all the routers of a backbone communicate. Tunnel connections do not need this address. Multicast connections are always established with the UDP protocol. Unlike TCP communication, an UDP telegram can always be lost. This is e.g. for WLAN connections very likely. Therefore, the routing backbone should always be realized with an Ethernet cable connection, as this is almost 100% transmission safe.

Backbonekey The routing protocol communicates in secure mode with encrypted telegrams. The key for encryption must be the same for all participants and is loaded into the device. The ETS generates the necessary backbone key on its own.

Tunnelling A KNX point-to-point connection on the TCP / IP network, which is established with UDP or TCP protocol. Tunneling communication is reliable and has incorporated a link layer for that purpose. Therefore independent of the ethernet connection, e.g. Cable or WLAN, and regardless of the TCP / IP protocol (UDP or TCP), no data is lost. With UDP, however, the restriction is that the data link layer works with a one-second timeout. For Enertex devices, this timeout can be adjusted in the advanced setup.

Telnet A simple TCP server on port 23 that enables direct text-based communication with the IP device. Telnet is a de facto standard used at the window level, e.g. with "Putty" is addressed.

Secure Mode If the device is parameterized via the ETS so that the communication is only encrypted, this is referred to as secure mode.

Plain Mode If the device is parameterized via the ETS so that the communication is only unencrypted, this is called unsecured mode.

ETS 5.6.6 and ETS 5.7.1

Version requirements

For error-free operation of the devices in secure mode, ETS 5.7.x or higher is required.

In plain mode, the device can basically be programmed as of ETS 5.6.6. Although the secure mode can be parameterized, it is not fully implemented in this version. If the device is therefore to be operated secure, we recommend working with version 5.7 or higher.

Special behavior

If you program the individual address in the ETS 5.6.6 with its own and a tunnel connection, the ETS will throw an error message at the end. This is to be ignored, the assignment of the address has nevertheless been made.

If no tunnel addresses are assigned in the application, all tunnels are set by the ETS to 15.15.255. Communication via the tunnel connection can then be considerably disturbed or not possible.

If the device is integrated in a secure project, the ETS saves the parameterization of this particular device including secure parameters. If the device is reset to factory settings, the ETS (5.6 or 5.7) only addresses the device in encrypted form. Therefore, communication with the ETS can no longer be established. In this case, only deleting the application and restarting the ETS will help.

If an update of Windows runs in the background, strange phenomenon can occasionally occur with the communication between the device and the ETS. In this case, wait for the end of the update and restart Windows.

Topology

To insert the interface into an ETS project, a TP line must exist.

Device Properties

General




Figure 1: Properties of the device

Name Any name can be assigned, max. 30 characters

Secure Commissioning If activated, the encryption is active for commissioning: all parameters are then transmitted in encrypted form, although e.g. Tunnel connections are still unencrypted.

Secure Tunneling If activated, the tunnel connections can only be established via KNX Secure Tunneling.

IP Properties




Abbildung 2: IP Einstellungen des Geräts

Obtain an IP address automatically The device requires a DHCP server for IP address assignment

Use a static address The user specifies the IP settings.

Commissioning Password A password from which the ETS generates a key. This is the key to secure commissioning (see above).

Authentication Code With the authentication password, the user proves that he has access to the project.

MAC Address Is a device property

Multicast Address Is given by the backbone configuration (see Fehler: Referenz nicht gefunden).

Device-specific parameters

General




Figure 3: General settings of the device

Name	Options	Description
(Text)		The ETS has manufacturer-independent uniform parameter dialogs for various settings. To simplify the application, a note text is displayed here.
Enable Special Functions	<u>off</u> /on	Enertex® devices offer special functions to ensure a maximum of flexibility.

Special Functions

Standard tunnel preferred IP

Enertex® devices offer the possibility for standard tunnel connections (before 2019) to assign each of these tunnel connections to an IP address. In the analysis of group telegrams, this makes it easier to assign the telegrams to the sender which "sits" behind the tunnel, as e.g. Visualizations or smartphone apps.

Note:

This assignment can be resolved at any time by the ETS or a new so-called extended tunnel connection (as of 2019).

1.1.1 Enertex KNX IP Secure Interface > Standard tunnelling

IP Settings

Telegrammrate

Standard tunnelling

Tunnelling

Slow Connection (UDP Clients only) off on

UDP Connection Timeout sec

If a connection is running e.g. over the Internet the normal timeout (1s) can be too small.
Parameter range is [1.0 .. 8.0] seconds.

A standard tunnelling connection (so called BasicCRI, devices upto ETS4) can not determine which tunnel to be used for a connection request. With this feature the tunnels are preferably assigned to an IP address.

Note, this is a weak assignment. Management connections or (new) extended CRI connections will override this assignment.

Preferred IP for Tunnel 1 off on

Preferred IP for Tunnel 2 off on

End device IP

Preferred IP for Tunnel 3 off on

Preferred IP for Tunnel 4 off on

Preferred IP for Tunnel 5 off on

Preferred IP for Tunnel 6 off on

Preferred IP for Tunnel 7 off on

Preferred IP for Tunnel 8 off on

Figure 4: Preferred IP for Tunnelling

Name	Options	Description
Slow Connection	<u>off/on</u>	The tunnel connections over UDP are controlled by default with a connection timeout of 1 second. This may be too short for connections over the Internet.
UDP Connection Timeout	<u>1,0 ... 8,0</u> sec	Tunnel X should preferably be used for communication with the parametrized IP address.
Preferred IP for Tunnel X	<u>off/on</u>	
End device IP	(IP-V4 Address)	

Telnet

Telnet can be used to request additional information from the IP Interface. Telnet access is factory-protected with the password "knxsecure".

Once the Interface is in secure mode, the telnet interface is disabled.

Although it can be enabled for developer purposes prior to programming the secure mode, this is a security risk.

<code>help</code>	Displays all available commands
<code>ifconfig</code>	Displays network parameters <pre>IP mode.....: DHCP IP.....: 192.168.33.142 Subnet mask...: 255.255.0.0 Gateway.....: 192.168.33.1 NTP server...: 192.53.103.108 Sys multicast.: 224.0.23.12 RT multicast..: 224.0.23.12 Hardware addr.: 00:50:c2:79:3f:ff</pre> <p>Sys multicast: Multicast address for System telegrams RT multicast: Multicast address für routingt telegrams</p>
<code>ifconfig [help dhcp ip mask]</code>	Set network parameters via the telnet interface. Expamples Setting IP Adresse with DHCP: <code>ifconfig dhcp</code> Statically set the IP address to 192.168.1.2 (in this case, the gateway and mask should also be adapted, see below) <code>ifconfig ip 192.168.1.2</code> Set the gateway to 192.168.1.1: <code>ifconfig gw 192.168.1.1</code> Set the mask to 255.255.255.0: <code>ifconfig mask 255.255.255.0</code>
<code>tpconfig</code>	Show KNX parameters <pre>KNX bus state.: up KNX address...: 15.15.000 Serial number.: 00-a6-00-00-00-01</pre>
<code>tpconfig [help set]</code>	Set KNX parameters via the telnet interface. Set the TP address to 1.1.0: <code>tpconfig set 1.1.0</code>
<code>progmode [0 1]</code>	Query or change programming mode (0 = off, 1 = on)
<code>apdu [55..248]</code>	Read or configure the maximum length of the KNX TP telegrams. This may be necessary if there is an incorrect implementation of a TP stack. In that case the ETS may try to use telegrams with 248 bytes payload, but the TP device can not proces (e.g. Zennio Z35j). Default is 248 and should only be changed if necessary. <pre># apdu maximal len of a KNX telegram 248. Usage: apdu [55 .. 248]</pre>
<code>tpratemax [5..50]</code>	Read or configure maximum telegram rate (IP => TP); 50 T / s corresponds to 100% bus load. <pre># tpratemax no limit, sending with maximum performance to TP. Usage: tpratemax [5 .. 50]</pre>


stats	<p>Shows various statistics on device and bus status</p> <pre> uptime: 114 days, 2:19 KNX communication statistics: TX to IP (all)...: 333729 (ca. 233 t/m) TX to KNX.....: 23244 (ca. 16 t/m) RX from KNX.....: 94559 (ca. 66 t/m) Overflow to IP..: 0 Overflow to KNX.: 0 TX tunnel re-req: 260 TP bus voltage...: 28.95 V TX TP rate.....: 50 T/s (= 100 %) </pre> <p>Uptime: Runtime of the interface since last restart TX to IP (all): Number of all telegrams sent on IP TX to KNX: Number of all telegrams sent on KNX RX from KNX: number of telegrams received from the KNX bus Overflow to IP: Number of telegrams that could not be sent to IP Overflow to KNX: Number of telegrams that could not be sent to the KNX bus TX tunnel re-req: Number of telegrams that had to be repeated in the tunnel connections TP bus voltage: Current bus voltage (at the time of calling stats) TX TP rate: maximum telegram rate (TP)</p>
free [clear]	<p>Shows statistics about the memory usage</p> <pre> Used stack memory...: 14 % Allocated memory....: 64 % Unused memory.....: 35 % TP-Tx buffer.....: 0 % TP-Tx buffer max....: 0 % TP-Rx buffer max....: 0 % Tunnel-T8 buffer max: 92 % </pre> <p>Used stack memory: Function stack utilization Allocated memory: Allocated device memory Unused memory: Unused device memory TP-Tx buffer: Currently used TP send buffer TP-Tx buffer max:Max. Utilization of TP send buffer (IP => TP) since system startup TP-Rx buffer max:Max. Utilization TP receive buffer (IP <= TP) since system startup Tunnel-XX (XX=1..8) buffer max:Max. Utilization of the tunneling buffer. Only tunnels whose buffer was used at all will be displayed</p> <p>Clear the buffer statistics: free clear</p>
tunnel [1..8]	<p>Shows active tunnel connections (without argument) or detailed information about the specified tunnel connection (with argument 1..8)</p> <pre> # tunnel Tunnels open: 1/8 1: 00.02.246, closed 2: 00.02.247, open (CCID: 82) 3: 00.02.248, closed 4: 00.02.249, closed 5: 00.02.250, closed 6: 00.02.251, closed 7: 00.02.252, closed 8: 00.02.253, closed </pre> <pre> # tunnel 2 Tunnel 2.....: open (CCID 82) KNX address.....: 00.02.247 HPAI control.....: 192.168.22.252:4808 HPAI data.....: 192.168.22.252:4808 Connect. type.....: TUNNEL_CONNECTION Communication.....: UDP CONNECTION TX tun req.....: 23169 TX tun re-req.....: 0 RX tun req.....: 821 RX tun re-req (identified): 0 RX tun req (wrong seq.)...: 0 Current tunnel buffer.....: 0 % Connected since (UTC).....: 16:26:16 29-01-2019 </pre> <p>CCID: Connection ID of the tunnel connection KNX address: Tunnelling address HPAI control: Control endpoint of the connection partner HPAI data: Data endpoint of the connection partner Connect. Type:Connection type tunnel or management connection Communication: UDP or TCP Connection TX tun req: Number of telegrams sent to the tunnel connection TX tun re-req: Number of telegrams that had to be repeated in the tunnel connections RX tun req: Number of telegrams received from the tunnel connections RX tun re-req: Number of telegrams received twice by the tunnel connections RX tun req (wrong seq.):number of frames received from the tunnel connections with wrong sequence number Current tunnel buffer: Utilization currently of the IP buffer of the tunnel Connected since (UTC): Time since the tunnel connection has been established.</p>
version	Firmware-Version
mask	Mask-Version
display [0 1]	Query or change the display mode (0 = standard, 1 = inverted)

tunaddr 1..8 address tunaddr reset tunaddr setall tunaddr help	KNX address of a tunnel read (tunaddr) or change, e.g. tunaddr 1 15.15.240, set all tunnel addresses consecutively from a certain start address (tunaddr setall 15.15.15), or reset the KNX addresses of all tunnels to factory settings (tunaddr reset) # tunaddr 1: KNX address: 15.15.010 2: KNX address: 15.15.011 3: KNX address: 15.15.012 4: KNX address: 15.15.013 5: KNX address: 15.15.014 6: KNX address: 15.15.015 7: KNX address: 15.15.016 8: KNX address: 15.15.017
tunmode [std/tpblk]	Read tunnel mode (without parameters) or set (tp or tpblk); tunmode tpblock:IP => KNX if same backbone forward to line frame KNX=> IP if same sub line send to backbone
Tunneltime [1.0..8.0]	Query or change timeout for tunnel connection (1.0 to 8.0). Setting is identical to "slow connection", Figure 4
tunudp	Query or change the type of tunnel connection for the ETS (0 = default, 1 = UDP only).
date	Show date and time
sntp [query server IP]	Send request to the NTP server (sntp query) or set the IP of the NTP server (sntp server 1.2.3.4)
logmem	Event memory in the device. Suitable for the development of clients. Read out for support requests.
passwd oldpw newpw passwd oldpw passwd newpw	Changes the current Telnet password (passwd), deletes the current password (old passwd) or sets a new password if none is currently set (new passwd)
secure [0 1]	Display or change the behavior of the Telnet interface in secure mode (0 = disable, default, 1 = enable) Note: Although it can be enabled for developer purposes prior to programming the secure mode, this is a security risk.
factory_reset	Reset to factory settings and reboot
die	Test hardware watchdog. Executes reset.
reboot	reboot
logout	end Telnet-Session

Latest documentation and Software

Under <http://www.enertex.de/d-produkt.html> you will find the current ETS database file as well as the current product description.

Specification

Symbols	 - Must not be disposed of with household waste.
KNX (Powersupply)	DC 21 ... 32 V SELV current consumption < 20 mA
Ethernet-Interface	Rj45-connector 10M/100MBit Ethernet
Display	Graphical OLED, 128x64 Programming LED (red), Bus Activity LED (yellow), Voltage LED (green flashing) Network link (green), network activity (yellow)

KNX Functions	<ul style="list-style-type: none"> • KNXIP Secure Tunneling • Up to 48 telegrams per second • AES 128 encryption • Asymmetric key exchange for tunnel connections • UDP and TCP communication • Up to 8 tunnel connections • APDU 248, parameterizable between 55 and 248 • TP telegram rate limit • TP bus voltage measurement (display telnet or display)
Environment	-5 ... +45° C
Installation	<ul style="list-style-type: none"> • Only for use in dry interiors. • Only for installation in distributor according to DIN 43880 on DIN rail 35mm according to EN 50022. • Degree of protection IP20
Outer dimensions	35,0 mm x 89,6 mm x 62,9 mm (L x B x H)

Open Source Software

This product uses third-party software from the following authors:

Adam Dunkels <adam@sics.se>

Marc Boucher <marc@mbsi.ca> and David Haas <dhaas@alum.rpi.edu>

Guy Lancaster <lancasterg@acm.org>, Global Election Systems Inc.

Martin Husemann <martin@NetBSD.org>.

Van Jacobson (van@helios.ee.lbl.gov)

Paul Mackerras, paulus@cs.anu.edu.au,

Christiaan Simons <christiaan.simons@axon.tv>

Jani Monoses <jani@iv.ro>

Leon Woestenberg <leon.woestenberg@gmx.net>

LWIP

Quelle: <https://savannah.nongnu.org/projects/lwip/>

Copyright (c) 2001-2004 Swedish Institute of Computer Science.
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.